


# **SEAVIEW**

**ELEVATE YOUR ELECTRONICS**



## **INSTALLATION INSTRUCTIONS**


For Seaview Modular Top Plate:

**ADA-S4**

Refer to website for most up to  
date instructions and videos.

**[WWW.SEAVIEWGLOBAL.COM](http://WWW.SEAVIEWGLOBAL.COM)**


# PARTS INCLUDED



**X1**




**X4**




**X4**

1/4 - 20




**X8**

5/16-18 x 1"



**X4**

1/4 - 20 x 1"




**X4**


5/16-18 x 1 1/2"




**X8**



**X1**




**X1**






**X1**


# TOOLS NEEDED



Sudbury Elastomeric Marine Sealant is recommended. To purchase call 800-655-7922 or visit [www.seaviewglobal.com](http://www.seaviewglobal.com)



**1** Secure the lower adapter plate to the Seaview mount with the eight 5/16-18x1" bolts and nylon washers.




**2**

Insert the four nuts into the top adapter plate as shown. Then insert the rubber grommet into the hole, making sure that the lip fits into the grommet.



**TIP**

Place the connector of the cable into a plastic bag. Apply Vasoline to the exterior of the plastic bag. Then try routing the connector/cable through the black rubber grommet.




# 3

Insert the four 1/4-20 x 1" bolts into the adapter plate as shown.




# 4

Attach the satellite dome to the adapter plate, and secure onto the four 1/4-20 x 1" bolts.




**5** Apply marine adhesive sealant to the circular groove on the underside of the top adapter plate. Route the cables through the adapter plates and rubber grommet. And secure the adapter plates together with the four **5/16-18x1-1/2"** bolts and nylon shoulder washers.



# OPTIONAL ACCESSORIES


Call 800-655-7922 or visit [www.seaviewglobal.com](http://www.seaviewglobal.com) for available accessories.

## LIGHT BARS



### LTB-R


Fits closed dome radars.



### LTB-S


Fits 20" or smaller satdomes.

## LIGHT BAR TOPS




### LTBP-1197

Perko 1197 Light.




### LTBA-7800

Attwood LED Light.



### LTBU1A1197


Light Bar Top with Perko 1197 Light, can fit GPS.



### LTBU1A800

Light Bar Top with Attwood LED Light, can fit GPS.

## SPREADER KIT



### SP1-MOD

Allows user to mount GPS units or antennas onto a Seaview Modular Mount.

**This page is intentionally left blank.**

The background of the entire page is a light gray topographic map with white contour lines. The lines are irregular and wavy, representing terrain elevation. The map covers the entire page, with the text elements overlaid on it.

***SEAVIEW//***  
***ELEVATE YOUR ELECTRONICS***

***SEAVIEW//***

Tel: 800-655-7922  
[www.seaviewglobal.com](http://www.seaviewglobal.com)

***EUROPEAN OFFICE***

Tel: +33 4 94 53 27 70  
[www.seaviewprogress.com](http://www.seaviewprogress.com)

2-122318